

# FLO-WARE™ For Windows™



For use with  
Flo-Dar™ and Flo-Tote™  
Flowmeters

**T**he Flo-Ware™ for Windows Model T200 is your ideal data management and Flowmeter communication software package. This powerful Windows based software program will efficiently and economically process your important flow data. You will immediately realize significant cost savings due to the many automated features designed into Flo-Ware. Professional looking reports can be created within minutes. Flo-Ware for Windows software was designed for use by computer novices and experts alike.

## ***Ideal Applications***

***Billing Purposes***


***EPA Permitting Requirements***

***Inflow and infiltration Studies***


***Combined Sewer Overflow  
Monitoring***

***Flow Proportional Sampling***

The software consists of the main program and separate instrument modules for the Flo-Dar and Flo-Tote flowmeters. The instrument module along with the Flo-Ware base package allows for instrument communication and reporting of your collected flow data. Flo-Ware's base package provides Chart Reports, Text Reports, Data Editing, Data Reconstruction, Text Report Designer, International Languages, and Language Designer – all included in an easy-to-use, feature rich program. An instrument module is also available for a popular rain gauge allowing you to present your rain data along with flow data in one presentation.



- Chart Reports
- Text Reports
- Scatter Plots



***Manage Your Flowmeters From Anywhere!  
Ask us about Wired, Wireless and  
World Wide Web Solutions***

**Marsh-McBirney, Inc.**  
[www.marsh-mcBirney.com](http://www.marsh-mcBirney.com)

Features that make  
a difference...

- Windows 95/98/2000/Me/NT/XP/ Pocket PC 2002 Compatibility
- Remote Communication via Supplied Modem
- Pre-Formatted Text Reports
- Create Professional Reports in Minutes
- Manage Your Flowmeters From Anywhere! Ask us about Wired, Wireless and World Wide Web Solutions
- Data Reconstruction; Data Editing with Find and Replace
- Supports International Languages
- Web Site Support with free downloads and help files
- Flo-Ware for Windows Training Course available

## FLO-WARE™ SPECIFICATION

### GENERAL

Windows 32 bit (Windows 95/98/2000/Me/NT/XP/Pocket PC 2002)  
Modular design supports instrument "plug in" drivers  
Multiple document interface  
Foreign language support  
Network provisions

### COMMUNICATIONS (Operates with Flo-Dar and Flo-Tote Flowmeters)

#### Site Setup

- Setup site attributes
- Tracks setups
- Calibration support

#### Read Meter

- Upload instrument data
- Instrument vital signs

#### Real Time

- On-Site system diagnostics
- Realtime reporting of data
- Spectrum analysis, vital signs where applicable

#### View Data

- Table view of stored data
- Supports sorting
- Network provisions

#### Preferences

### REPORTING

User defined file dates/times  
User defined data intervals  
File appending  
Import different file types into same project (i.e., flow, rainfall)  
Custom theme support  
Full color, presentation quality charts  
Scatter plots  
Pre-formatted text reports

### DATA EDITING

- Single point editing
- Find/Replace
- Advanced data reconstruction workspace
- Scatter plots
- Point & click relationship builder
- Save relationship tables for future use
- Repair data with reconstruct table
- Text report designer

### INSTRUMENT MODULE

**Rainger Rain Gauges** - Supports Savannah Environmental, Inc. Rainger Rainfall Event Logger

### SOFTWARE REGISTRATION

Register-to-use program - Owner is required to register the software via phone, fax, or e-mail within 14 days after installation.

**FILE COMPATIBILITY** - Flo-Ware is backwards compatible with earlier versions of Flo-Ware Software data files.

### COMPUTER SYSTEM REQUIREMENTS Hardware

**Recommended:** Pentium II or higher processor running at least 200 MHz with 64 MB RAM or more. Graphics card and monitor must be capable of 800x600 pixels running in 16 bit (65,000) colors.

**Minimum:** Pentium or equal processor running at least 90 MHz with 16 MB RAM. Graphics card and monitor must be capable of 800x600 pixels running in 16 bit (65,000) colors.

### ORDERING INFORMATION

The Flo-Ware for Windows Software Model T200 is a data management and instrument communication software package for Flo-Dar and Flo-Tote Flowmeters. The software package includes an instrument driver, chart reports; text reports; data editing; text report designer; and language designer, site set-up; data collection; real time; calibration, computer interface cable, and manual. Software is provided on CD only. Floppy disc copies can be produced from the CD supplied. Printed copies of manuals available optionally. Flo-Ware for Windows Training course available. Flo-Ware Software is also compatible with Flo-Ware FX software for Pocket PC (available from Savannah Environmental).

Marsh-McBirney, Inc, the Marsh-McBirney logo, Flo-Dar and Flo-Tote are trademarks of Marsh-McBirney, Inc. All other trademarks represented in this document are trademarks of their respective owners.



Marsh-McBirney, Inc.  
4539 Metropolitan Ct. • Frederick, MD 21704-9452 U.S.A.  
(800) 368-2723 • (301) 874-5599 • FAX (301) 874-2172

www.marsh-mcBirney.com  
ISO 9000:2000 Certified Mfg. Facility



SIRA CERTIFICATION SERVICE  
SUPPLIER QUALITY MANAGEMENT CERTIFICATE NO.940070



Made in U.S.A. under one or more of the following patent numbers:  
4015471, 4083246, 4459848, 4549434, 4688432, 4455870, 4669308, 4821580, 5313842, 5385056 and 5811688.

P/N 103001201, 2.5M 11/03